

## BACON TOAST. No 1.

CUT some bacon into rather thin slices; place them in a frying pan with just enough water to cover, and boil for a few seconds. Then drain the slices and fry quickly over a hot fire until the bacon is a delicate brown. Have ready some slices of well-buttered, toasted brown bread, trimmed to the size of the bacon; put the hot bacon on the toast. Place a small slice of fried sweet potato (this can be fried in the bacon fat) on the top of each slice of bacon and send to the table very hot.